



Installation Guide

Tools you need:


1. Ratchet
2. Socket 7mm
3. Socket 10mm
4. Socket 8mm
5. Spanner 10mm
6. Spanner 17mm
7. Hand Plier

Start here:

1. Removing stock air intake pipe by pulling up.
(Open your engine hood and let it cool for 15 minutes at least when your engine is hot.)




2. Remove stated 10mm screws as below by using socket 10mm.



3. Pull out the PCV connector.



4. Remove the clip with hand plier.




5. Pull out the stock air box carefully.



6. Remove the clip from PCV pipe with hand plier and pull the plastic connector out.



7. Use hand plier to loosen the clip and rotate its direction as picture show below.



8. Use the given screw set and follow the installation steps below on the engine valve cover hole.






Installation Guide

9. Apply 1pcs washer on the top of the heat shield.




10. Assembly the given blue silicone hose and stainless steel clips.



11. Apply clip and install the PCV pipe to new intake rampipe.




12. Install the intake rampipe carefully.



13. Tighten the spring washer & nut together with 17mm spanner.



14. Tight up 10mm screw which located under the intake rampipe.





Installation Guide

15. Lastly, install the air filter and tighten with socket 8mm.
(**Precaution: Adjust the proper height of air filter to prevent damaging hood insulator**)



CONGRATULATIONS ++ horsepower